FRONT CROSSMEMBER (ASSY)



F25871A

Symbol meaning

REMOVAL	A M A : Remove Weld Points	: Cut with disc sander, etc.
INSTALLATION	O M I : MIG Plug Weld	: Tack Weld

F25871B

REMOVAL·INSTALLATION



mm (in.)

F25871

INSTALLATION POINT

1 Inspect the fitting of the related parts around the new parts before welding. This affects the appearance of the finish.
2 Temporarily install the new parts and measure each part of the new parts in accordance with the body dimension diagram. (See the body dimension diagram)
3 After applying the top coat, apply anti-rust agent to the internal panel portion of the closed section structural weld points.